



FINE-TUNING TIPS FOR **RAIN RFID** APPLICATIONS



Increase Reader Power

If you are missing tag reads, adjust the reader power incrementally, increasing by no more than 1.5 dBm at a time.



Lower Reader Power

If you are experiencing stray reads, decrease the reader power in small steps of no more than 1.5 dBm.



Adjust RSSI

If reducing reader power doesn't mitigate stray reads, lower the RSSI in your reader software to filter out tags outside the desired read zone.

